

POTIS N S.S.LED + DALI

ΙΟΥΛ 2021


οδηγίες τοποθέτησης






ΤΟΠΟΘΕΤΗΣΗ ΑΝΤΑΠΤΟΡΑ


1 Επιλέξτε κύκλωμα 0.




2 Τοποθετήστε τον αντάπτορα στη ράγα.




3 Γυρίστε τον μηχανισμό στερέωσης.




4 Επιλέξτε το επιθυμητό κύκλωμα.



5 Γυρίστε τον μηχανισμό DALI για τη μηχανική στερέωση.






ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ

- Η εγκατάσταση πρέπει να γίνεται από αδειούχο ηλεκτρολόγο.
- Εφόσον υπάρχει ακροδέκτης γείωσης, συνδέστε τον στη γείωση της εγκατάστασης.
- Βεβαιωθείτε ότι η παροχή είναι απενεργοποιημένη κατά τη συντήρηση.
- Η ισχύς των λαμπτήρων δεν πρέπει να υπερβαίνει την ένδειξη στο φωτιστικό ή στη συσκευασία.
- Μετά την εγκατάσταση ελέγξτε τη στερέωση και τη σύσφιξη των στυπιοθλιπτών, όπου υπάρχουν.
- Ο κατασκευαστής δεν ευθύνεται για τραυματισμούς ή ζημιές από λανθασμένη εγκατάσταση ή χρήση.
- Δεν προορίζεται για βρογχοειδή σύνδεση.
- Τα ούπα και οι κλέμες δεν περιλαμβάνονται.
- Τα στοιχεία LED αντικαθίστανται μόνο από τον κατασκευαστή.

ΠΡΟΣΟΧΗ

Φοράτε αντιστατικά γάντια όταν αγγίζετε τα LED.



ΠΡΟΣΟΧΗ

Αντικαταστήστε τυχόν ραγισμένο γυαλί.




BRIGHT
ΕΙΔΙΚΟΣ ΦΩΤΙΣΜΟΣ


GREENLIGHT

POTIS N S.S.LED + DALI

JUL 2021


installation instructions






INSTALL THE ADAPTER


1 Select 0 circuit.




2 Fit adapter on track.




3 Turn the mechanical fixing knob.




4 Select the desired circuit.



5 Turn the DALI knob for mechanical fixing.






USER INSTRUCTIONS

- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the mains is switched off during servicing.
- Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.
- LED modules are replaced only by the manufacturer.

CAUTION

Wear anti-static gloves
before you touch LED systems



CAUTION

Replace any cracked shield



GREENLIGHT