
SERO

MAP 2023


οδηγίες τοποθέτησης

εσωτερικού χώρου / επίτοιχα




1 **Εγκατάσταση**

Αφαιρέστε τον λαμπτήρα από τη λαμπτοθήκη.




2


Ξεβιδώστε το εσωτερικό μέρος για πρόσβαση στη βάση.



3

Κάντε τις ηλεκτρικές συνδέσεις. Βιδώστε τη βάση στον τοίχο.





4 Τοποθετήστε τον λαμπτήρα.




5

ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ


- Η εγκατάσταση πρέπει να γίνεται από αδειούχο ηλεκτρολόγο.
- Εφόσον υπάρχει ακροδέκτης γείωσης, συνδέστε τον στη γείωση της εγκατάστασης.
- Απενεργοποιήστε την παροχή κατά τη συντήρηση.
- Η ισχύς των λαμπτήρων δεν πρέπει να υπερβαίνει την ένδειξη στο φωτιστικό ή στη συσκευασία.
- Μετά την εγκατάσταση ελέγξτε τη στερέωση και τη σύσφιξη των στυπιοθλιπτών, όπου υπάρχουν.
- Ο κατασκευαστής δεν ευθύνεται για τραυματισμούς ή ζημιές από λανθασμένη εγκατάσταση ή χρήση.
- Δεν προορίζεται για βρογχοειδή σύνδεση.
- Τα ούπα και οι κλέμες δεν περιλαμβάνονται.
- Τα στοιχεία LED αντικαθίστανται μόνο από τον κατασκευαστή.

ΠΡΟΣΟΧΗ

Φοράτε αντιστατικά γάντια πριν αγγίξετε τα συστήματα LED.



Αντικαταστήστε τυχόν ραγισμένο γυαλί.



BRIGHT ΕΙΔΙΚΟΣ ΦΩΤΙΣΜΟΣ

Εργοστάσιο

Κεφαλοβρύσου 5, Μονομάτι, Αχαρνές, Τ.Κ. 13677, Αθήνα, Ελλάδα | Τηλ: (+30) 210 6208 230

E-mail: info@bright.gr | www.bright.gr

GREENLIGHT


SERO

MAR 2023


installation instructions

indoor/ wall







1 **Installation**
Detach the lamp from the lampholder.




2
Unscrew the inner part to access the base.



3 Make wiring connections.
Screw the base on the wall.





4 Fit the lamp




5

USER INSTRUCTIONS


- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the mains is switched off during servicing.
- Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.
- LED modules are replaced only by the manufacturer.

CAUTION

Wear anti-static gloves
before you touch LED systems



Replace any cracked shield



BRIGHT SPECIAL LIGHTING

Factory
5 Kefalovrisou Str., Monomati, Acharnai, P.O. Box 13677, Athens, Greece | Tel: (+30) 210 6208 230
E-mail: info@bright.gr | www.bright.gr

GREENLIGHT