JULY 2018


TORRIS 3 CEILING

οδηγίες τοποθέτησης


εσωτερικού χώρου / φωτιστικά




Εργαλεία
εξαρτήματα



Σημειώστε τις οπές.
Στερεώστε το έλασμα στην οροφή.






Βιδώστε το
καλώδιο γείωσης στο
μεταλλικό
έλασμα.



Σφίξτε τις βίδες για να στερεωθεί
το φωτιστικό στην οροφή.

Τοποθετήστε τον λαμπτήρα και λυγίστε
το ελατήριο
μέσα στο φωτιστικό.



ΟΔΗΓΙΕΣ ΕΓΚΑΤΑΣΤΑΣΗΣ

- Η εγκατάσταση πρέπει να γίνεται από αδειούχο ηλεκτρολόγο.
- Εφόσον υπάρχει ακροδέκτης γείωσης, συνδέστε τον στη γείωση της εγκατάστασης.
- Απενεργοποιήστε την παροχή κατά τη συντήρηση.
- Η ισχύς των λαμπτήρων δεν πρέπει να υπερβαίνει την ένδειξη στο φωτιστικό ή στη συσκευασία.
- Μετά την εγκατάσταση ελέγξτε τη στερέωση και τη σύσφιξη των στυπιοθλιπτών, όπου υπάρχουν.
- Ο κατασκευαστής δεν ευθύνεται για τραυματισμούς ή ζημιές από λανθασμένη εγκατάσταση ή χρήση.
- Δεν προορίζεται για βρογχοειδή σύνδεση.
- Τα ούπα και οι κλέμες δεν περιλαμβάνονται.

BRIGHT
ΕΙΔΙΚΟΣ ΦΩΤΙΣΜΟΣ

Εργοστάσιο
Κεφαλοβρύσου 5, Μονομάτι, Αχαρνές, Τ.Κ. 13677, Αθήνα, Ελλάδα | Τηλ: (+30) 210 6208 230
E-mail: info@bright.gr | www.bright.gr

GREENLIGHT

TORRIS 3 CEILING


JULY 2018

installation instructions


indoor/ interior lighting




Tool accessories




Make hole pattern
Fit the metal stripe on ceiling






Screw the earth wiring on the metal strip



Tighten the screws to secure the fixture on ceiling

Fit the lamp and bend the spring in the fixture



USER INSTRUCTIONS

- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the mains is switched off during servicing.
- Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.

BRIGHT SPECIAL LIGHTING

Factory
5 Kefalovrisou Str., Monomati, Acharnai, P.O. Box 13677, Athens, Greece | Tel: (+30) 210 6208 230
E-mail: info@bright.gr | www.bright.gr

GREENLIGHT