## NOTUS 3 LINEAR LED

(a) indoor/ profile

110

92mm


Cut hole on


ceiling.


Remove

the cover.

⊛







Access profile and make wiring connections.


■ Please notice the screw washer between the

modules.



- •The unit must be earthed in case an earth connecting point exists.
- Ensure that the mains is switched off during servicing.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- •The unit is not intended to operate in loop connection.
- •Wall plugs and terminals are not included.
- •LED modules are replaced only by the manufacturer.

CAUTION







Hilb

ON















Attach the heatsink and the cover



