

# MINI AVOLO A WALL

## installation instructions

indoor/



### 1 Installation

A. Make holes on wall and adjust metal strip  
B. Make wiring connection  
C. Adjust base on wall

### 2 Lamp replacement

Ensure that the mains is switched off during servicing,  
● before you replace the lamp

Detach the glass out of the fixture.

### 3

Replace the lamp.

### 4

Bend the spring and fit the glass and shade back

### 5

**USER INSTRUCTIONS**

- The installation of the unit must be done by a qualified electrician.
- The unit must be earthed in case an earth connecting point exists.
- Ensure that the mains is switched off during servicing.
- Do not use bulb(s) bigger than the indicated on units name-plate or packaging.
- Ensure that after the installation, the unit is properly fixed and the cable clamps (if exist) are well tightened.
- Manufacturer will not accept liability for injury or damage resulting from incorrect use or installation
- The unit is not intended to operate in loop connection.
- Wall plugs and terminals are not included.

**CAUTION**  
Replace any cracked shield



**Factory**

5 Kefalovrisou Str., Monomati, Acharnai, P.O. Box 13677, Athens, Greece | Tel: (+30) 210 6208 230  
E-mail: info@bright.gr | www.bright.gr